



DX-D50, DX-D70, DX-S2Pro, DX-D100, NX-5PRO, NX-100PRO, NX-80, NX-65U

## System Chart for Nikon SLR Housings

### MACRO




### WIDE



\*\* : No apparent image aberration  
\* : Image aberration is sometimes apparent

### SUPER MACRO



**Lenses with this mark are compatible**

|                 |               |
|-----------------|---------------|
| 65 = NX-65U     | 100 = DX-D100 |
| 80 = NX-80      | S2 = DX-S2Pro |
| 100 = NX-100PRO | D70 = DX-D70  |
| 5 = NX-5PRO     | D50 = DX-D50  |

\*1: Focus is adjustable with the focus knob on housing (main-body)  
\*2: Zoom is controllable with the focus knob on the housing (main-body)  
\*3: Focus is adjustable with the focus knob on the port.  
\*4: Zoom is adjustable with the zoom knob on the port.  
\*5: Manual focus cannot be used.



Aperture Gear for Nikon Lens [56700]



Aperture Gear for Nikon Tele-converter X2 [56720]